

Harness Adjuster Button Remedy Kit:

- Non-Toxic, Food-Grade Lubricant
- Remedy Label
- No Tools Required

Harness Adjuster Remedy Instructions

IMPORTANT: For more information about this remedy kit, its components, and a video detailing these instructions, please visit www.britax.co.nz/clicktight-recall.aspx.

1. Unbuckle the vehicle seat belt and open the CLICKTIGHT (Fig. 1).

- a. Press the dimple on the CLICKTIGHT dial.
- b. Rotate dial clockwise until CLICKTIGHT releases and lift to open.

NOTE: You do not need to remove your child seat from the vehicle.

2. Locate the harness adjuster button (red) on the underside of the CLICKTIGHT (Fig. 2).

3. Squeeze the tabs on both sides of the harness adjuster button and pull the button out of the CLICKTIGHT (Fig. 3).

4. Tear the tab on the lubricant tube to open and apply a thin layer around the sides of the harness adjuster button (Fig. 4).

5. Slide the harness adjuster button back into the channel on the underside of the CLICKTIGHT (Fig. 5).

NOTE: Ensure that the harness adjuster button is installed with the wider side at the top.

6. Discard any excess lubricant and the applicator, then wash your hands.

7. Lift the right front of the seat cover and apply the provided remedy label next to date of manufacture label on seat pan (Fig. 6), then write in the date on the line provided.

8. Buckle the vehicle seat belt and close the CLICKTIGHT.

- A click confirms the CLICKTIGHT is secure.

9. Secure your child in the seat and pull forward on the harness straps to confirm proper function and snugness of the harness can be achieved. If you have any questions or concerns, please contact BRITAX Consumer Service.

